

# Handle Assembly



The handle assembly attaches to the yoke of the pin driver. The trigger initiates the driving of the wedge pins into the couplers. Release of the trigger reverses the operation.

## MERKMALE

Handle is adjustable for various application orientations

Simple trigger operation

## SPEZIFIKATIONEN

Table 1/1

| Katalognummer | Stückgewicht |
|---------------|--------------|
| ML541         | 0.45 kg      |

## ZUSÄTZLICHE PRODUKTDDETAILS

Prior to installation, please read and understand the detailed instructions and safety notices provided in the nVent LENTON Quick Wedge Operator's Manual.

## WARNUNG

nVent-Produkte müssen in Übereinstimmung mit den Produktinformationsblättern und dem Schulungsmaterial von nVent installiert und verwendet werden. Informationsblätter sind verfügbar unter [www.nVent.com](http://www.nVent.com) sowie bei Ihrem nVent-Kundendienstvertreter. Unsachgemäße Installation, Missbrauch, Fehlanwendung oder andere Handlungen im Widerspruch zu den Anweisungen und Warnungen von nVent können zu Fehlfunktionen, Anlagenschäden, schwerer Körperverletzung sowie zum Tod führen und/oder haben die Annullierung der Garantie zur Folge.

#### Nordamerika

+1.800.753.9221

Option 1 – Kundendienst

Option 2 – Technischer

Support

#### Europa

Niederlande:

+31 800-0200135

Frankreich:

+33 800 901 793

#### Europa

Deutschland:

800 1890272

Sonstige Länder:

+31 13 5835404

#### APAC

Shanghai:

+ 86 21 2412 1618/19

Sydney:

+61 2 9751 8500



Unser starkes markenportfolio:

**CADDY**

**ERICO**

**HOFFMAN**

**ILSCO**

**SCHROFF**

**TRACHTE**