


Interscale Mounting Bracket

Servizi di distribuzione di energia



The bracket enables mounting an Interscale case to a wall or allows a distance between the mounting surface and the rear wall.

CERTIFICAZIONI



CARATTERISTICHE

Able to assemble / disassemble case while mounted

Provides 14 mm clearance from mounting surface for cable management

Bracket for wall or recessed mounting

SPECIFICHE

Table 1/1

Numero catalogo	Package Quantity
24820-005	4

ADDITIONAL PRODUCT DETAILS

Not compatible with embedded NUC cases or Interscale M 19" cases.

AVVERTENZA

AVVERTENZA: i prodotti nVent devono essere installati e usati solo secondo le indicazioni riportate nei fogli delle istruzioni del prodotto nVent e nei materiali di formazione. I fogli di istruzioni sono disponibili sul sito www.nvent.com e presso il vostro rappresentante locale dell'assistenza clienti di nVent. Un'installazione scorretta, l'uso improprio, l'applicazione errata o altre inosservanze delle istruzioni e delle avvertenze di nVent possono causare un malfunzionamento del prodotto, danni alle proprietà, lesioni corporee gravi e morte e/o l'annullamento della garanzia.



Our powerful portfolio of brands:

CADDY ERICO HOFFMAN ILSCO SCHROFF TRACHTE