

Interscale Mounting Bracket

Strømforsyning



The bracket enables mounting an Interscale case to a wall or allows a distance between the mounting surface and the rear wall.

SERTIFISERINGER



FUNKSJONER

Able to assemble / disassemble case while mounted

Provides 14 mm clearance from mounting surface for cable management

Bracket for wall or recessed mounting

SPESIFIKASJONER

Table 1/1

Katalognummer	Package Quantity
24820-005	4

ADDITIONAL PRODUCT DETAILS

Not compatible with embedded NUC cases or Interscale M 19" cases.

ADVARSEL

nVent-produkter skal kun installeres og brukes som angitt i nVents produktinstruksjonsark og opplæringsmateriell. Instruksjonsark er tilgjengelige på www.nvent.com og fra nVent-kundeservicerepresentanten din. Feil installasjon, misbruk, feil bruk eller annen unnlatelse av å følge nVents instruksjoner og advarsler i deres helhet kan forårsake produktfeil, skade på eiendom, alvorlig personskade og død og/eller ugyldiggjøre garantien din.



Our powerful portfolio of brands:

CADDY ERICO HOFFMAN ILSCO SCHROFF TRACHTE