


Interscale Mounting Bracket

Instalacje zasilające



The bracket enables mounting an Interscale case to a wall or allows a distance between the mounting surface and the rear wall.

CERTYFIKATY



FUNKCJE

Able to assemble / disassemble case while mounted

Provides 14 mm clearance from mounting surface for cable management

Bracket for wall or recessed mounting

OKREŚLENIU SPECYFIKACJI

Table 1/1

Numer katalogowy	Package Quantity
24820-005	4

ADDITIONAL PRODUCT DETAILS

Not compatible with embedded NUC cases or Interscale M 19" cases.

OSTRZEŻENIE

Produkty nVent powinny być instalowane i używane wyłącznie zgodnie z instrukcjami i materiałami szkoleniowymi nVent. Instrukcje są dostępne na stronie www.nvent.com oraz u przedstawiciela działu obsługi klienta firmy nVent. Nieprawidłowa instalacja, niewłaściwe użycie, niewłaściwe zastosowanie lub inne nieprzestrzeganie instrukcji i ostrzeżeń nVent może spowodować nieprawidłowe działanie produktu, uszkodzenie mienia, poważne obrażenia ciała i śmierć i/lub utratę gwarancji.



Our powerful portfolio of brands:

CADDY ERICO HOFFMAN ILSCO SCHROFF TRACHTE