






UAV



Ref.	Pic.	Qty.
A		3
B		1
C		1



It is highly recommended to install two air vents per enclosure for sufficient air circulation.